

Instructions for installing vinyl stack wall(s)

* Read all steps prior to beginning installation.

** List of supplies to have on-hand prior to beginning installation:

- Can of white spray paint
- (2) 5-gallon buckets
- Sponges
- Water
- Grout applying float (optional)

STEP 1: Apply self-supplied white spray paint to edge of wall sections to mask panel anchors. Set aside to dry. (This only needs to be done on the edge that will go up against wall)

STEP 2: Apply two beads of silicone to single piece of vinyl. Adhere vinyl to floor surface or shower base. Apply two beads of silicone to top of vinyl piece. (You may want to do a dry run (no silicone) with the 1st section to get a better idea of where the wall will end up)

STEP 3: Starting with panel section labeled “1” or “1A” slide panel anchor into top piece of vinyl. Stack first panel onto vinyl previously adhered to floor surface or shower base, level the panel, screw anchors into wall, and apply two beads of silicone along strip of vinyl at top of panel section. Repeat steps for each panel section(s).

STEP 4: Mix your self-supplied grout and apply to joints in between glass blocks. (Do not grout seam between glass block wall and your existing wall or seam between glass block wall and your floor surface or shower base.)

This may be done using a grout bag to pip into the joints, then use rubber float to pack and remove excess. Work in small sections if you are unfamiliar with this process.

STEP 5: Prior to being completely cured, use your slightly damp self-supplied sponge and in a gentle, circular motion smooth out grout. Rinse sponge frequently.

STEP 6: After grout has dried, apply bead of silicone to seam between glass block wall and your existing wall. Also, apply bead of silicone to seam between glass block wall and your floor surface or shower base.