

Instructions for installing vinyl stack window(s)-Multi Piece

* Read all steps prior to beginning installation.

** List of supplies to have on-hand prior to beginning installation:

- Can of white spray paint
- (2) 5-gallon buckets
- Sponges
- Water
- Grout applying float (optional) or Bakers Bag or Trowel
- Wood Shims

STEP 1: Apply self-supplied white spray paint to edge of window sections. Set aside to dry.

STEP 2: Apply two beads of silicone to single piece of vinyl. Adhere vinyl to frame. Apply two beads of silicone to top of vinyl piece.

STEP 3: Starting with panel section labeled “1” or “1A” slide panel anchor into top piece of vinyl. Stack first panel onto vinyl previously adhered to floor surface or shower base, level the panel, screw anchors into wall, and apply two beads of silicone along strip of vinyl at top of panel section. Repeat steps for each panel section(s).

STEP 4: Once window is secured in opening using either a Bakers Bag or a trowel fill in perimeter with mortar on the inside and outside of the window as to make sure the mortar is solid all the way through.

STEP 5: Mix your self-supplied grout and apply to joints in between glass blocks.

STEP 6: Prior to being completely cured, use your slightly damp self-supplied sponge and in a gentle, circular motion smooth out grout. Rinse sponge frequently.