

Instructions for installing vinyl stack window(s)

* Read all steps prior to beginning installation.

** List of supplies to have on-hand prior to beginning installation:

- (2) 5-gallon bucket
- Mortar
- Sponge
- Water (to mix with Mortar)
- Bakers Bag or Trowel
- Wood Shims

STEP 1: Using Wood Shims, center window in rough opening.

STEP 2: Once window is secured in opening using either a Bakers Bag or a trowel fill in perimeter with mortar on the inside and outside of the window as to make sure the mortar is solid all the way through.

STEP 3: Once mortar has began to cure, remove wood shims and fill the space with mortar using your Bakers Bag or trowel.

STEP 4: Prior to being completely cured, use your slightly damp self-supplied sponge and in a gentle, circular motion smooth out grout. Rinse sponge frequently.