

# Shower Shelf Installation Guide



Read this entire installation guide before beginning your installation.

InnovaShowers Wall Panels are 100% waterproof, we recommend the use of a siliconized sealer like DAP® or SilTex in the seams for added protection. Follow your local building codes for wet environments like shower and tub enclosures. We recommend using the 'Acceptable Substrates' listed to the right to prevent water from getting behind potentially unsealed areas that would cause mold or other damage.

Acceptable Substrates: include existing ceramic tile walls, Cement Board®, Schluter Kerdi Board®, GP DensShield®, Johns Manville GoBoard®, HardieBacker®, Fiberrock®, moisture resistant greenboard, and equivalent products. Always follow manufacturer's installation instructions to create a waterproof enclosure.

## What is included:

- 1 - Shelf
- 2 - Brackets
- 4 - Screws  
(stainless steel)



## Tools and supplies needed:

- Protective eye wear
- Level
- Screwdriver or screw gun
- Caulking gun for 10.3 oz. adhesive tubes
- Adhesive for PVC panels (**Recommended adhesives: Loctite® Titebond Titegrab Ultimate™ and Manus 75-AM HV) PowerGrab Ultimate (white formula), LIQUID NAILS® FUZE\*IT®, (In Canada, use Lepage® No More Nails Wet Grab)**)
- Silicone-based sealant

## Step 1



After locating where you want to place the shelf, put adhesive onto bracket.

*Note: The shelf should be installed after the InnovaShower Wall Panels are completed*

**NOTE:**  
If panels are installed over existing tile



If panels are installed over existing tile, you will need to use 1/4" tapered anchors (examples above). Follow anchor install instructions to install anchors, but use the stainless steel screws provided with the shelf.

## Step 2



Install the first screw closest to the corner of the shower.

## Step 2 continued



Before installing the second screw, be sure to level the bracket.

## Step 2 continued



Repeat the same process for the other bracket.

## Step 3



Before installing the shelf, place a bead of adhesive on both inside edges of the shelf. Placing adhesive here will help eliminate glue pushing out onto the outside surfaces of the shelf.

(continued on next page)



After you have applied the adhesive, place a small bead of sealant along the edges that will go against the shower wall.



Continue to push the shelf into place for a tight fit against the wall.



Carefully slide the shelf onto the brackets.



Wipe off any excess sealant that pushes out or add sealant in areas needed.

